

FIGURE SC03

Testable single check valve for low hazard rated applications Flanged and roll grooved connections



GENERAL APPLICATION

The SC03 provides low hazard protection from both backsiphonage and backpressure of the potable water supply in fire system applications.

TECHNICAL DATA


Size range: Temperature rating: Working pressure: End connections: DN 80 - 150 1°C to 60°C PN16 Flanged AS 4087 Flanged AS 2129 Roll grooved AS 2638 Alternative flange drillings may be available on request

FEATURES

- Short body length to allow the replacement of conventional non-testable check valves.
- Supplied with lifting lugs to assist with installation.
- Compact simple design.
- In-line and on-site serviceable.
- No special tools required for servicing.
- Designed and manufactured in accordance with requirements of AS/NZS 2845.1.
- FBE coated to AS/NZS 4158.
- Straight through flow path for maximum flow co-efficient.
- Top entry allows all parts to be accessed easily.
- Stainless steel internals for superior corrosion resistance.
- Fully restrained check valve assemblies for unrivalled safety.
- Each valve is factory bench tested and tracked with unique serial number.
- All internal components are repairable or replaceable.
- All internal and external bolting is stainless steel.
- Installations can be vertical and horizontal.
- Conforms to the testing requirements of AS/NZS 2845.3.
- Anti-tamper test taps provided as standard.
- Assembly can be supplied with lockable isolating valves.







PRINCIPLE OF OPERATION

Under dynamic flow conditions

Pressure builds up in the upstream chamber before the check valve assembly. When pressure is sufficient (minimum of 7 kPa) check valve assembly will open allowing flow into the system pipe work.

Under backpressure conditions


(Premises pressure is greater than supply pressure)

Water pressure in system pipe work and spring pressure force the check valve assembly closed.


Under backsiphonage conditions

[Negative supply pressure in mains supply] Water pressure in the upstream chamber before the check valve assembly will dissipate and the check valve assembly will close under spring pressure.


FIGURE SC03








Note: resilient seated gate (RSGV) valve arrangement illustrated.



Note: butterfly valve (BFV) arrangement illustrated.



 $\textbf{Note:} \ gear \ op \ butterfly \ (G/OP) \ arrangement \ illustrated.$

DIMENSIONS (mm)

Valve size				Mass (kg)			
DN	Α	В	C/D	V0	RSGV	BFV	G/OP
80	400	815	492	19	84	31	42
100	420	885	525	31	115	50	60
150	500	1040	612	68	178	92	103

NOTE

Dimensions are nominal to $\pm~1~\text{mm}$

Butterfly valve actuators change from handles to gear operators on valve sizes DN 150 and above.

Gear operation actuators available on request for butterfly valve arrangement.


Lockable actuators available on request.

VO = Mass of valve only.

RSGV = Mass of complete arrangement with resilient seated gate valves.

BFV = Mass of complete arrangement with butterfly valves.

G/OP = Mass of complete arrangement with gear actuated butterfly valves.




Note: valve only (VO) illustrated.

DIMENSIONS (mm)

Valve size							Mass
DN	Α	В	С	D	E	F	(kg)
100	380	252	165	230	15.9	114.3	23
150	450	350	220	300	15.9	168.3	46

TYPICAL FLOW CHARACTERISTIC GRAPHS

16 kPa standard spring configuration DN 80 - 100 - 150



50 kPa optional spring configuration DN 80 - 100 - 150




FIGURE SC03

SELECTION GUIDE


Example:		100	SC03	С	FS	BF
Valve size	(DN)					
Figure no.						
End conne	ctions					
С	Flanged AS 4087					
E	Flanged AS 2129					
R/G	Roll grooved AS 2638					
	Alternative flange drillings may be available on reque	st				
Assembly						
VO	Valve only					
FS	Fire service (supplied without strainer)					
Isolation						
BF	Butterfly valves					
BF G/Op	Butterfly valves gear actuated					
BF G/Op L	L Butterfly valves gear actuated lockable					
RSGV	Resilient seating gate valves					

NOTE

All Emerson isolation valves come with the provision for locking.

TROUBLESHOOTING GUIDE

I KOOBLESHOOTING GOIDE				
Symptom	Cause	Remedy		
First check valve not holding tight	1. Debris fouling the check valve seal	1. Inspect, clean, reverse or replace check seal		
(reading approaches zero without holding)	2. Check valve seal damaged or perished	2. Inspect and replace check valve seal		
	3. Check valve 0-ring damaged	3. Inspect and replace O-ring		
	4. Check valve stem 0-ring damaged	4. Inspect and replace O-ring		
	5. Check valve seal ring damaged	5. Replace first check valve assembly		
Check valve holding below 7 kPa	1. Debris fouling the check valve seal	1. Inspect, clean, reverse or replace check seal		
	2. Check valve seal damaged	2. Inspect and replace check valve seal		
	3. Check valve spring memory loss or damaged	3. Replace first check valve assembly		
	4. Check valve stem 0-ring damaged	4. Check valve stem 0-ring damaged		



PARTS LIST

FARTSLIST					
Description					
Cover plate					
Cover plate bolts					
Cover plate 0-ring					
Check valve circlip					
Check valve seal ring					
Check valve O-ring					
Check valve seal					
Check valve disc					
Check valve stem					
Check valve stem 0-ring					
Check valve spring					
Check valve retaining nut					

FIGURE SC03

Complete safety and maintenance instructions for testable single check valve

MAINTENANCE AND TESTING REQUIREMENTS

Test after initial installation and annually for the life of the valve or service. Maintain in a working order and inspect for operational function at intervals not exceeding twelve months. The functions are to be carried out by authorized licensed backflow testers.

DISASSEMBLY INSTRUCTIONS

As described in the safety precautions, slowly close isolation valves and the open test taps 1 and 2 to exhaust line pressure.

Remove cover plate bolts [2] and washers.

Remove cover plate [1] and cover plate

O-ring [3].

With a screwdriver remove check valve assembly circlip (4) utilizing cavity recess in the body casting.

NOTE

Please take care and do not chip FBE coating with screwdriver.

To remove check valve assembly pull check valve stem/spring (9 and 11) out and then upwards through the top entry of the valve.

Check valve assembly, please use the following steps to access check valve seal (7). Using two spanners, fit one spanner to the check valve stem head (9) and the other to the check valve retaining nut (12), turn check valve retaining nut anti-clockwise and remove.

Remove check valve disc (8), to expose the check valve seal (7) for servicing or replacement.

NOTE

When reassembling:

- Clean and lubricate all O-rings.
- Check valve seal (7) must be clean, free of any greases, moisture and debris to ensure a positive seal.

SAFETY PRECAUTIONS

In every instance of installation or removal from the pipeline, ensure the line is not pressurized and any hazardous liquid is drained away. Slowly close both isolating valves and then open test taps 1 and 2 to exhaust line pressure.

Recommended specifications for testable single check valve



- Main valve shall be manufactured in accordance with AS/NZS 2845.1.
- Main valve shall be constructed form ductile iron and FBE coated to AS/NZS 4158.
- All internals shall be constructed from stainless steel and to have a pressure rating of PN16 and a temperature rating of 60°C.
- Main valve body shall not form part of the wetted check valve sealing area or mechanism.
- All internal components and elastomer seals shall be accessible through a top entry point of the main valve to allow inline maintenance.
- Valve test points shall also be fitted with BSPT threads to allow testing to AS/NZS 2845.3.
- Main valve to have flanged connections in accordance with AS 4087 or AS 2129 or roll grooved ends to AS 2638.

Neither Emerson, Emerson Automation Solutions, nor any of their affiliated entities assumes responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use, and maintenance of any product remains solely with the purchaser and end user.

ValvCheQ is a mark owned by one of the companies in the Emerson Automation Solutions business unit of Emerson Electric Co. Emerson Automation Solutions, Emerson and the Emerson logo are trademarks and service marks of Emerson Electric Co. All other marks are the property of their respective owners.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.

Emerson.com/FinalControl