805Y, 805YR, 805YB 3/4" - 2"







Modification Overview

Production of the ³/₄ - 2" 805Y series began in 1973 and was discontinued in 2003.

Production of the 805YR began in 1994 in ¾" and 1" sizes only. This version had replaceable check seats. Discontinued in 2003.

Production of the 805YB began in 1995 and is still used as a bypass assembly for certain models of DCDA.

Check Cover Removal

Cover is threaded into body and o-ring sealed.

Cover is spring loaded.

Loosen cover with wrench, then remove by hand while holding tightly against spring pressure.







Check Valve Removal

Poppet style check valve.

The poppet and spring are free once the cover is removed.



Check Seat Removal

Earlier models of the 805Y do not have replaceable seats.

805YR and 805YB have replaceable seats.

Seats are threaded and o-ring sealed.







Check Disc Replacement

Remove screw and disc washer from poppet. American Backflow Products Company

Check Valve Reassembly Notes

Inspect and clean the guide bore on the cover.

The stem must move freely in the guide bore.

Reassemble in reverse order.



